

WALL

Manufacturer	MEVA	EcoFix	AluFix	AluStar	AluStarTec	StarTec XT	Mammut 350	Mammut XT	Imperial	MevaLite	PERI	DUO	MAXIMO	RUNDFLEX	RAPID	TRIO	VARIO	RINGER	Alu 2000	Stahl 2000	Alu Master	Stahl Master	UNI-SPAN	UniLite	E/F Panel	BIM²	Steel-Ply
Models																											
Revit Models	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
IFC Walls & Project Families	☑*	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Linked Revit Models	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Linked IFC Models	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Properties																											
Storage Manager	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Settings	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Automatic Forming																											
Forming Across Cycles	☑*	☑	☑	☑	☑	☑	☑	☑	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	☑*	
AllIntersection	☑*	☑	☑	☑	☑	☑	☑	☑	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	☑*	
Forming in Partial Steps																											
Part Wall Types	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Standard Cases (90° Corners, T-Wall, Intersections)	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Pillar Template	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Articulated Corners	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Wall Offset	-	-	-	-	-	-	-	-	-	-	-	-	-	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Freestanding	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Forming	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Cycle Connections	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
LyingExtension	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Timber Filler End of Wall	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Timber Filler Middle Wall	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Timber Filler Split	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Automatic Accessories	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Standard Accessories (Locks, Ties, Alignment)	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Scaffolding Brackets	☑*	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	-	-	-	-	-	-	-	-	-	-	-	-	
Brace Frames	☑*	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	-	-	-	-	-	-	-	-	-	-	-	-	
Vertical Rails for horizontal Expansion	☑*	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	-	-	-	-	-	-	-	-	-	-	-	-	
Forming Column	☑*	☑	☑	N/A	N/A	N/A	N/A	N/A	N/A	N/A	☑*	N/A	N/A	N/A	☑	N/A	N/A	-	-	N/A	N/A	N/A	N/A	-	N/A	N/A	N/A
Place Single Elements																											
Standard Options	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Place on Face	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Place with Distance	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	-	-	-	-	-	-	-	-	-	-	☑	
Place Single Accessories																											
Assembly Lock	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
TieRod	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Timber Filler	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Alignment Rail	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Bolting on Articulated Corners	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
StopEnd	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	N/A	N/A	-	-	-	-	-	-	-	-	-	-	-	
Place Single Accessories by Points																											
Assembly Lock	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
TieRod	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
Alignment Rail	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
Brace Frame	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
Scaffolding Bracket	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
Sloping Support	☑*	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	-	N/A	-	-	-	-	-	-	-	-	-	-	-	
Modify																											
Turn Lettering	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Hide Text	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
HideTie Lines	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
Hide Multi Function Lines	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	
ConcreteFace	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	

Legend:



Function available without restrictions



Function not available



Function restricted/not available for all systems



Only available for Manufacturer Pro version



Not Applicable

SLAB

Manufacturer	MEVA	MEP	MT60	MEVA32	AluFix	MevaDec	VarioMax	MevaFlex	PERI	PERI UP Flex	DUO	SKYDECK	SKYMAX	MULTIFLEX	RINGER	AluDEK	RingerFlex	Uni-span	UniStage	UniFlex
Shoring					--	--	--	--												
Settings	☑	☑	☑	☑	--	--	--	--	☑	☑	--	--	--	--	--	--	--	☑	☑	--
Spindle Height Selection	--	--	--	--	--	--	--	--	☑	☑	--	--	--	--	--	--	--	☑	☑	--
Tower Head Selection	☑	☑	☑	☑	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
Side Extension	☑	☑	☑	☑	--	--	--	--	☑	☑	--	--	--	--	--	--	--	☑	☑	--
Corner Extension	☑	☑	☑	☑	--	--	--	--	--	--	--	--	--	--	--	--	--	☑	☑	--
Modular Slab																				
Settings	☑	--	--	--	☑	☑	--	--	☑	--	☑	☑	☑	--	☑	☑	--	--	--	--
Start Command	☑	--	--	--	☑	☑	--	--	☑	--	☑	☑	☑	--	☑	☑	--	--	--	--
Standard Area	☑	--	--	--	☑	☑	--	--	☑	--	☑	☑	☑	--	☑	☑	--	--	--	--
Compensation Area	☑	--	--	--	☑	☑	--	--	☑	--	☑	☑	☑	--	☑	☑	--	--	--	--
Smallest Compensation		--	--	--	☑	☑	--	--	--	--	--	--	--	--	--	--	--	--	--	--
Compensation with Flex		--	--	--	☑	☑	--	--	--	--	--	--	--	--	--	--	--	--	--	--
Place Single Accessories	☑	--	--	--	☑	☑	--	--	*	--	*	--	*	--	--	*	--	--	--	--
Compensation Beam		--	--	--	☑	☑	--	--		--	☑	☑	☑	--	--	☑	--	--	--	--
Support Panel		--	--	--	☑	☑	--	--		--	☑	☑	☑	--	--	--	--	--	--	--
Panel Connector		--	--	--	☑	☑	--	--		--	☑	☑	☑	--	--	☑	--	--	--	--
Turn Lettering	☑	--	--	--	☑	☑	--	--	☑	--	☑	☑	☑	--	☑	☑	--	--	--	--
Flex Slab																				
Settings	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Flex Start Command	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Closed Room Selection		--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Edge Selection		--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Precast Support	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Place Single Elements	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Primary Beam	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Secondary Beam	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑
Forming Face	☑	--	--	--	--	--	☑	☑	☑	--	--	--	--	☑	☑	--	☑	☑	--	☑

Legend:



--



N/A

Function available without restrictions

Function not available

Function restricted/not available for all systems

Only available for Manufacturer Pro version

Not Applicable

MANAGE

Manufacturer	MEVA	PERI	RINGER	Uni-span	BIM ²
Export					
Total Quantity	☑	☑	☑	☑	☑
Export Schedule	☑	☑	☑	☑	☑
Export Selection	☑	☑	☑	☑	☑
Custom Export	☑	☑	☑	☑	☑
Families					
Dissolve Nested Families	☑	☑	☑	☑	☑
Change Group Phases	☑	☑	☑	☑	☑
Parameters					
Change Project Language	☑	☑	☑	☑	☑
Sheets					
Copy/Create Sheet	☑	☑	☑	☑	☑
Visuals					
Colour Phases	☑	☑	☑	☑	☑
Project Cleanup					
Remove Duplicate Objects	☑	☑	☑	☑	☑
Browser	☑	☑	☑	☑	☑
Content					
Manufacturer Content	☑	☑	☑	☑	☑

Legend:



Function available without restrictions

--

Function not available



Function restricted/not available for all systems



Only available for Manufacturer Pro version

N/A

Not Applicable

CONTENT

Manufacturer	MEVA	PERI	RINGER	Uni-span	BIM ²
Wall	EcoAs, Mammut, Circo, CaroFalt, STB, Triplex, Securit Basic MIS	MXK-Bracket	--	--	--
Slab	Form Set, Props	Props (MULTIPROP, PEP Ergo, PEP Alpha), MULTIPROP Tower	Props	Props	--
Working Scaffolds	LAB 130, KAB 190, SPACE, BKB	PERI UP	--	--	--
Climbing	--	SCS	--	--	--

Legend:

- 

Function available without restrictions
- Function not available
- 

Function restricted/not available for all systems
- 

Only available for Manufacturer Pro version
- N/A

Not Applicable